

# **MAGRINI NAPPY CHANGING UNIT**

## **Models KBCS – Vertical / KBHS – Horizontal**

### **Cleaning Instructions**

To ensure that the changing table retains its original colour and good looks a regular cleaning routine is essential.

The nappy changing unit may be washed and wiped with a damp soft cloth or sponge. Use of mild detergent and warm water will remove the majority of dust and stains. For more obstinate stains a domestic cream cleaner can be used such as 'Cif' or similar. If in doubt please contact your supplier. Do not use any caustic or solvent cleaners as this may damage the unit. An anti-bacterial spray should be used on the folding bed and wiped dry ready for use.

Safety straps are made from Polypropylene and can be hand or machine washed at up to 50°C. They should be dried in warm air but do not tumble dry. The straps must not be ironed as they will melt.

Straps can be washed or wiped clean with soap or soap powder but we cannot recommend the use of any other detergents or chemicals as they have not been tested.

### **Maintenance instructions**

Stand in front of the unit and check that the front label is in place

Open door and check that the four wall mounting fixings are secure

Check the safety strap is securely attached to the unit at each side

Open and close the snap-lock buckle several times checking that, when pulled by hand, it does not come apart. Replace if necessary.

Ensure warning label is in place on the inside of the unit and general cleanliness is within given guidelines.

### **Product Warranty**

Magrini warrants its Baby Changing Units to be free from defects in materials and workmanship, under normal use and service, for a periods of one year from the date of purchase, when installed and maintained in accordance with Magrini's written instructions.

Without limiting the generality of the foregoing, this warranty does not cover:-  
disposable bed liners, product misuse, theft or vandalism, tampering or misapplication, loads in excess of stated maxima or improper installation.

Magrini's liability will be limited, at Magrini's option, to repair or replacement with respect to any claim made within the applicable warranty period referred to above.



**Magrini Ltd** Unit 5 Maybrook Industrial Estate, Brownhills,  
Walsall, West Midlands WS8 7DG

**Tel: 01543 375311 Fax: 01543 361172**

**E-mail: sales@magrini.co.uk**